JATCO RL4F02A


PART NUMBER 93897S

Splined Repair Insert

938975

1 Planetary Carrier Insert





Installation Instructions

- 1. Chuck the carrier assembly in a lathe on the hardened race diameter. Ensure that chuck runout does not exceed .002". Bore out the old internal spline. This bored diameter should yield a slip fit with the 35mm pilot diameter of the repair insert.
- 2. Now counter bore the outside surface of the carrier to clear the 40mm flange diameter of the repair insert. Counter bore depth requirement is 2mm to yield a flush surface between the insert flange and carrier.
- 3. Weld the joint around the flange O.D., then machine flush any weld protrusion.

