


## **Centering Tool Instructions**

## T3-SML-TOOL



- 1. Insert **T3-SML-TOOL** centering tool into large centering feature in tube pilot end of yoke (see illustration).
- 2. Mount centering tool and yoke in lathe using 60° centers on each end. Live center should be used on tailstock end (standard or bullnose style).
- 3. Turn tube pilot diameter to required size for proper fit with driveshaft tubing.

©2007 Sonnax Industries, Inc. T3-SML-TOOL 04-17-07