

CHRYSLER RWD, LATE 1970-2002

NEUTRAL SAFETY BACK-UP INSULATOR SERVICE KIT

Features & Benefits:

- Direct replacement
- Securely fastens to the detent lever (rooster-comb) with a 1/8" diameter steel pop rivet
- Eliminates searching through cores for a usable detent lever



Part No.

22229-03

1 Insulator

1 Steel Pop Rivet

Note: Only for units with 3 terminal switch. Does not fit 2002 and newer with digital range sensor.



Replace missing, cracked or broken insulators and eliminate the chance of returning fatigued or brittle OE parts to service.

Note: The rivet must be installed as described below or damage to the insulator will occur. Ease the insulator into place on the detent lever carefully to avoid damaging the plastic material.

INSTALLATION INSTRUCTIONS:

- Remove the old OEM solid rivet from the detent lever by drilling it out or by using a suitable punch to drive it out. Care must be taken to avoid enlarging the hole through the detent lever.
- Install the insulator so that the plastic barbs snap over the detent lever edge.
- Install the pop rivet as shown. Make sure the end of the rivet passes through the insulator before it passes through the detent lever. The flat head of the rivet should butt against the plastic of the insulator.
- To set the pop rivet you will need a standard pop rivet tool with a Ø1/8" nose piece.



22229-03(in) 03-07-05