TF-80/81SC, TF-60SN

PART NUMBERS 15741-29K, F-15741-TL29

Lockup Clutch Control Valve Kit

15741-29K

- 1 Lockup Clutch Control Valve
- 1 Lockup Clutch Control Sleeve
- 1 Valve Cap
- 1 Spring
- 1 Spacer
- 1 Plunger Valve
- 1 Plunger Sleeve

F-15741-TL29


- 1 Reamer Jig
- 1 Guide Pin
- 1 Reamer



Required for TF-80SC & TF-60SN F-15741-TL29PL

- 1 Adapter Plate
- 3 Assorted Screws

Note: Fits Volvo (AM6); Opel (AF40); Peugeot (TF80); Saab (AF40/6); Land Rover (TF80); Ford (AF21); Mazda (AW6A-EL); BMW (6F21WA) & VW/Audi (09G, 09K, 09M).



Caution

Adapter plate **F-15741-TL29PL** is required to hold VW 09G (TF-60SN) and Volvo/Opal (TF-80SC) valve body sections while reaming. Adapter plate is not required for Ford/Mazda (TF-81SC).

Note: Mounting instructions are included with the Adapter plate F-15741-TL29PL.

Disassembly Steps

Remove the retainer, plunger sleeve with plunger valve, spring and lock-up valve. Keep the retainer for re-use and discard all other OE pieces.

Important Notes:


- 1. Clean the bore thoroughly in a solvent tank.
- 2. Generously lubricate the bore and reamer with cutting fluid (i.e. Mobilmet S-122, Lubegard Bio-Tap, Tap MagicTM, etc). For best results, provide a continuous flow of water-soluble cutting fluid (i.e. Mobilmet S-122) during the reaming process.
- 3. The reamers should be turned using a low rpm, high torque air drill regulated to a maximum of 200 rpm.
- 4. Examine the bore after cleaning for surface finish, debris, and burrs. Flashing and burrs on the exit side of lands and bores must be carefully removed. A small piece of Scotchbrite™ material attached to a wire and powered with a drill motor is ideal for the task.



TF-80/81SC, TF-60SN

PART NUMBERS 15741-29K, F-15741-TL29

Lockup Clutch
Control Valve Kit



Installation & Assembly Steps

For 2003-2004 TF-60SN *only*:

- 1. Insert the Sonnax Lockup Clutch Control valve and sleeve assembly into the reamed bore with the smaller OD in-board.
- 2. Insert the Sonnax spring.
- 3. Insert the Sonnax plunger valve/sleeve assembly into the reamed bore with the open end in-board.
- 4. Install the OE plunger sleeve retainer*.



For TF-80/81SC and 2005-Up TF-60SN:

- 1. Insert the Sonnax Lockup Clutch Control valve, cap & sleeve assembly into the reamed bore with the smaller sleeve OD in-board.
- 2. Insert the Sonnax spring.
- 3. Insert the Sonnax sleeve spacer into the reamed bore.
- 4. Insert the Sonnax plunger valve/sleeve assembly into the reamed bore with the open end in-board.
- 5. Install the OE plunger sleeve retainer*.



* If the stack-up of components does not allow the installation of the retainer, carefully remove the minimum necessary material from:

'03-'04 TF-60SN Only: The open or inboard end of the plunger sleeve. Be sure to remove any burrs that may interfere with plunger valve movement.

TF-80/81SC & '05-Up TF-60SN: File the castelated side** of the sleeve spacer. Remove burrs.

