PART NUMBERS 36947-13K, F-36947-TL13

Oversized Manual Valve


VB-FIX Base Plate Modification

Extreme care must be used in clamping the valve body to the **VB-FIX** as currently designed, to ensure the manual valve bore does not warp. Once clamped in place, the Sonnax guide pin must stroke freely in the bore. To provide better support, the **VB-FIX** base plate can be modified by drilling and tapping four holes, as shown below. This will allow the base plate to be turned 90° and then secured to the clamp mounting plate, allowing more support for the manual valve during reaming.




Modification Measurements

Use these dimensions to drill and modify your base plate. Do not use image below as an actual template for modifications.



Vacuum test plate must cover all other related circuits

Critical! Check L/R modulator plunger sleeve for wear. Wear reduces vacuum and equals line loss in reverse.



VERIFICATION & VACUUM TEST PROCEDURE:

Perform a vacuum test at the location indicated. A vacuum test should reach at least 9" of vacuum.

For information on proper vacuum test procedures go to www.sonnax.com, click on "Technical Information" and go to the Vacuum Testing Guidelines section.

