


TORQUE CONVERTER PARTS

AL-HT-2HS

MODIFIED TURBINE HUB



MODIFICATION INSTRUCTIONS

Modifying the early-model stator for use with the early-model modified turbine hub **AL-HT-1HSM** or **AL-HT-2HS**:

- 1. Remove retaining pocket wall by machining flush with surface "A".
- 2. Machine the stator ID to 61.40-61.20mm (2.417-2.409") to accept AL-WS-1 or AL-WS-3.
- 3. Remove any burrs.

©2007 Sonnax Industries, Inc. AL-HT-2HS-IN 12-26-07