## A4LD, 4R44E & 4R55E

PART NUMBERS 56219-03K, -04K

### **Center Support/Forward Clutch Sleeve**

#### 56219-03K

1 Forward Clutch Sleeve



#### 56219-04K

1 Installation Tool1 Forward Clutch Sleeve




**Note:** Both parts fit '96 & earlier bushing style center supports only.




#### **Instructions:**

- 1. Start with a worn OEM center support.
- 2. Machine counterbore in the support.
- 3. Remove any chips from oil feed passage, and clean bore with a Loctite® compatible cleaner.
- 4. Apply an even coat of Loctite® 609 sleeve retainer to the OD of the sleeve and the ID of the support bore.



1. Start with a worn OEM center support



2. Machine a counterbore in the support



# A4LD, 4R44E & 4R55E

PART NUMBERS 56219-03K, -04K

#### **Instructions continued:**

- 5. When pressing the sleeve, support the center support at the thrust washer surface, not at the outer diameter.
- 6. Align hole in sleeve with feed hole in center support.
- 7. Use the installation tool **56219-04K** to press the sleeve into place.
- 8. Check forward clutch sealing ring end gap before installation.

