MERCEDES 722.6

PART NUMBERS 68942-10K, F-68942-TL10

TC Lockup Clutch Regulator Valve Kit

68942-10K

1 Valve


1 Spring



F-68942-TL10

- 1 Reamer
- 1 Reamer Jig
- 1 Guide Pin

Note: This sleeve will fit Chrysler 300 & 300C, '05-'07; Chrysler Aspen, '07; Chrysler Crossfire, '04-'07; Dodge Charger SRT, '06-'07; Dodge Magnum R/T, SXT, SRT-8, '05-'07; Dodge Nitro, '07; Dodge Sprinter Van, Diesel 2500-3500, '04-'07; Jeep Commander, '06-'07; and Jeep Grand Cherokee, Laredo and SRT-8, '05-'07.



Disassembly:

Disassemble the valve body and discard the OEM TC lockup clutch regulator valve and spring.

Reaming Instructions:

- 1. Clean bore thoroughly in a solvent tank.
- Align valve body on fixture according to VB-FIX instructions using jig F-68942-RJ10 and guide pin F-68942-GP10, then ream using F-68942-RM10.
- 3. The reamer should be turned either by hand using a speed handle or by a low rpm, high torque air drill regulated to a maximum of 200 rpm.
- 4. The reaming action should be clockwise in a smooth and continuous motion, at 60-200 rpm. The reamer should actually pull itself through the bore, so little or no forward force should be applied.
- 5. Continue reaming until the reamer stop is reached. Spin the reamer 5-10 more times after bore bottoming to allow for excess material removal and better surface finish.
- 6. Using low air pressure, blow the chips free before removing the reamer.
- 7. To remove the reamer, turn clockwise while slowly pulling outward on the reamer.

@2008

Cautions:

- 1. Never turn the reamer backward
- 2. Pushing on the reamer will result in poor surface finish, inadequate and sporadic material removal, and material being left un-reamed as the reamer exists the bore.
- 3. Using low pressure air blow any chips from the reamer after each use.
- $4.\ \mbox{Never}$ use a crescent wrench, t-handle or ratchet to turn the reamer.

Installation:

- 1. Thoroughly clean the valve body.
- 2. Install the Sonnax spring into the pocket of the Sonnax TC lockup clutch regulator valve.
- Insert assembled valve and spring into valve body bore as shown on above.
- 4. Install the OEM valve retaining plate.

