
4R70W (2001 & UP),

PART NUMBER 76507F-01K

Valve Body Retainer Plate

76507F-01K

- 1 Retainer Plate
- 1 Gasket
- 2 Bolts



Installation and Assembly Steps

Proper position of Retainer Plate sitting on valve body

Tools Required:

13/4" or #9 drill bits (sharp), 1/4" drill bit, 5/16" drill bit, 6.0mm x 1.0mm thread tap.


Preparation:

- 1. Install the separator plate onto the valve body & align the plate with the original alignment bolts.
- 2. Locate the two cast in-place bolt hole locations on underside of valve body (see Figure 1).
- 3. In a drill press use 5/16" drill bit to clean up the cast in-place bolt hole locations and establish a true center for drilling further with the 13/4" or #9 drill.

Warning: Do NOT drill deeper than ½6" with the ½6" drill bit! (see Figure 2).

- 4. After true center is established, use a ¹³/₆₄" or #9 drill to drill all the way through the valve body AND the separator plate with a piece of wood underneath to prevent the plate from deforming as the drill bit cuts through.
- 3. Remove the separator plate and enlarge the two drilled holes in the separator plate by re-drilling with a $\frac{1}{4}$ " drill bit. De-burr the new holes in the separator plate.
- 4. With a 6.0 x 1.0mm thread tap, cut new threads in the drilled holes in the valve body. De-burr the gasket surface, making sure there are no high spots from the drilling/tapping operations.

- 1. Assemble the valve body, lower valve body gasket, separator plate using normal procedures.
- 2. Install the Sonnax gasket, valve body retainer plate and two screws. Tighten screws to 80-100 lb-in (9-11 Nm).






Figure 2: Underside of 4R70W Valve Body

