4L60-E, '96 & '97, 4L80-E, '96


PART NUMBER 34913-01

34913-01

1 Shift Cable Conversion Bracket

NOTES: When top mount bosses are broken or damaged use the Sonnax bracket as an alternative to OEM brackets. Some cases may require drilling and threading of NSS bosses.

Vehicles with case-mounted NSS have longer manual shafts. If using an early case in a later vehicle, be sure to install longer manual shaft.



INSTRUCTIONS

Notes: NSS bosses on early cases may require drilling and threading.

Vehicles with case-mounted NSS have longer manual shafts. If using an early case in a later vehicle, be sure to install longer manual shaft.

If the transmission pan has an extended lip where the bracket mounts, the lip must be cut away. Remove the lip using a cut-off wheel so it is flush with remainder of pan



- 1. Install bracket so cable is mounted in same location as with OEM bracket.
- Reuse OEM top-mount bolts to install Sonnax bracket at pan location.
- 3. Apply thread-locking compound to bolts.
- 4. Tighten bolts to 7-10 ft. lbs. (4L60-E) or 18 ft. lbs. (4L80-E).
- 5. Install and adjust cable following standard procedures.



| Converts | To be used in |
|---|-------------------------|
| 1994-95 4L60-E Case | 1996-97 Vehicles |
| 1994-95 4L80-E Case | '96 Vehicles |
| | |
| Replaces OEM bracket for units with broken bosses | |
| 4L60-E | 1996-2000 CK Truck |
| Bracket Stamped 15995247 | 1996-2005 M/L Astro Van |
| 4L80-E | |
| Bracket Stamped 15995246 | 1996-1997 CK Truck |

Sonnax Bracket 34913-01

