## A404, A413, A470, A670


PART NUMBER 32539-Z5

## **Transfer Shaft Shim**

32539-Z5

10 Shims Transfer Shaft Shim

(.005" thick)



## **Installation Instructions**

Setting preload of the transfer shaft bearing requires a spacer of approximately 0.94mm (.037") thickness.

- 1. To determine the necessary spacer thickness, install a "gauge" spacer of .055" thickness.
- 2. Torque the retaining nut to 200ft. lb.
- 3. Measure the axial endplay of the transfer shaft.
- 4. The difference between the observed endplay and the endplay spec of .002" .010" is noted to determine the exact spacer required.

