PART NUMBER 36423-BPF


High Efficiency Internal Filter

36423-BPF

1 High Efficiency Internal Filter

REQUIRED TOOLS

1/8" Drill Bit 5/32" Drill Bit 10-32 Thread Tap




PREPARATION:

- 1. Drill and tap the valve body as shown (see Figure 1).
- 2. Reinstall valve body, but do not install the two bolts where the filter bracket will mount.

INSTALLATION:

- 1. Insert the feed hose/compression fitting onto the filter inlet.
- 2. Carefully tighten compression fitting with 9/16" & 5/8" wrenches.
- 3. Thread 10-32 feed screw into the valve body, but do not tighten at this time.
- 4. Install filter/bracket assembly onto the valve body and tighten in place while holding it snug against the valve body (see Figure 2).



©2008

- 5. Tighten 10-32 feed screw. Verify hose clamp tabs are pointing away from pan (see Figure 3).
- 6. Shift the linkage into low position and verify clearance between linkage lever and filter housing.
- 7. Verify clearance with pan.
- 8. Stamped text "out" should be closest to pan bottom (see Figure 2).

