## RE5R05A

PART NUMBERS 63741-09K, 63741-12K

### **Reverse Boost Valve Kits**

63741-09K

Late Style

1 Boost Sleeve

1 Boost Valve

63741-12K

Early Style

1 Spring

1 Boost Sleeve

1 Boost Valve

**Note:** Fits Nissan, Infinity RE5R05A and Kia A5SR1/A5SR2.

Also Available

# Oversized PR Valve & Reverse Boost Assembly

#### 63741-01K

1 Pressure Regulator Valve



1 Boost Sleeve

1 Boost Valve


#### F-63741-TL

1 Reamer

1 Guide Pin

1 Reamer Jig





#### **Notes or Cautions**

Use the diagram above to verify that you have the appropriate kit.

#### For 63741-09K - Late Style:

#### **Disassembly Steps**

- 1. Remove spring retainer.
- 2. Remove and discard OEM boost valve and boost sleeve. Do <u>not</u> discard OEM spring.

#### **Installation/Assembly Steps**

- 1. Install Sonnax boost valve assembly.
- 2. Install OEM pressure regulator spring.
- 3. Install OEM spring retainer.

#### For 63741-12K - Early Style:

#### **Disassembly Steps**

- 1. Remove spring retainer.
- 2. Remove and discard OEM boost valve, boost sleeve and the OEM spring.

#### **Installation/Assembly Steps**

- 1. Install Sonnax boost valve assembly.
- 2. Install Sonnax pressure regulator spring.
- 3. Install OEM spring retainer.

#### **Final Verification**

Wet Air Test (WAT) or vacuum test the boost valve assembly while in the bore at the outboard reverse feed port indicated. A minimum of 18" of vacuum should be reached. If performing a WAT, no leakage should occur at the neighboring exhaust port.

