JATCO/NISSAN

PART NUMBERS 113741-15K, F-113741-TL13

Oversized Secondary Pressure Regulator Valve Kit

113741-15K



1 O/S Secondary Pressure Regulator Valve

- 1 Spring
- 1 End Plug

NOTE: Fits JF010E only

F-113741-TL13










Tool Kit for 113741-15K can also be used for 113741-13K

NOTE: Sonnax tool kits designed to service a specific bore require the Sonnax VB-FIX, a self-aligning valve body reaming fixture. More information and instructions are available at www.sonnax.com.



Disassembly

- 1. Remove and discard the OEM valve, end plug and spring.
- 2. Keep the OEM retainer.

Important Notes

Tool Kit F-113741-13K contains two reamers.

For JF010E valve bodies, use reamer F-113741-RM15 only

- 1. Clean the bore thoroughly in a solvent tank.
- 2. Generously lubricate the bore and reamer with cutting fluid (i.e. Mobilmet S-122, Lubegard Bio-Tap, Tap Magic™, etc.). For best results, provide a continuous flow of water-soluble cutting fluid (i.e. Mobilment S-122) during the reaming process.
- 3. The reamers should be turned using a low RPM, high torque air drill regulated to a maximum of 200 RPM.
- 4. Examine the bore after cleaning for surface finish, debris, and burrs. Flashing and burrs on the exit side of land and bores must be carefully removed. A small piece of Scotchbrite™ material attached to a wire and powered with a drill motor is ideal for the task.

Cautions and Suggestions


- 1. Turning the reamer backward will dull it prematurely.
- 2. Pushing on the reamer will result in poor surface finish and inadequate and sporadic material removal.
- 3. Never use a crescent wrench, ratchet or pliers to turn the reamer.
- 4. A dull reamer will cut a smaller hole. Reamers can be sharpened, but should only be done by a professional tool sharpener. Actual life of a reamer before resharpening or replacing averages 50-70 bores.



JATCO/NISSAN CVT

PART NUMBERS 113741-15K, F-113741-TL13

Reaming Instructions



Installation

1. Remove all debris from the valve bores and body.


18 in-Hg

2. Install the Sonnax regulator valve and spring

- 3. Install the Sonnax end plug with the boss of the end plug inboard.
- 4. Reinstall the OEM retaining clip.

Final Verification Steps

A vacuum at the port indicated should yield 18" of vacuum or higher.



JF010E Main Valve Body

113741-15K Rev:-, F-113741-TL13 Rev:-, 113741-15K-IN 07-22-10