AXODE, AX4S

PART NUMBER 96201-29K

3-2 Shift Timing Valve Kit

96201-29K

1 Valve

1 Retainer



Bore Sizing Tool

96201-BST29


1 Bore Sizing Tool

Also Available

96201-10

10 Retainer Clips

Note: These retainers are applicable to numerous Ford valve body locations.



Disassembly:

- 1. Remove the pull-in assembly and clip to get to the 3-2 control valve.
- 2. Remove the 3-2 timing valve.

Bore Sizing Instructions:

- 1. Lubricate the bore sizing tool with ATF.
- 2. Insert the sizing tool into the bore. There will most likely be interference between the tool and the bore, so it may be necessary to use a hammer when inserting the bore sizing tool.
- 3. The handle of the tool is equiped with a 3/8-16 UNC thread for use with a slide hammer.
- 4. Clean the bore of any debris.
- 5. Lubricate the OEM valve and bore with ATF.

Install parts in the following order:

- 1. Sonnax 3-2 shift timing valve.
- 2. OEM spring, Sonnax retainer.
- 3. OEM spring.
- 4. OEM pull-in valve.
- 5. OEM end plug.

©2007

6. OEM or Sonnax retainer clip, 96201-10.

