

PART NUMBERS 56947-14K, -SML, -MED, -LRG

# **End Plugs**

### 56947-14K

- 2 Small End Plugs
- 3 Small End Plug O-Rings
- 1 Medium End Plug
- 2 Medium End Plug O-Rings
- 3 Large End Plugs
- 4 Large End Plug O-Rings

#### 56947-SML

- 3 Small End Plugs
- 4 Small End Plug O-Rings


### 56947-MED

- 3 Medium End Plugs
- 4 Medium End Plug O-Rings

# 56947-LRG

- 3 Large End Plugs
- 4 Large End Plug O-Rings

**Note:** Additional o-rings have been added to kits.



### **Wet Air Test**

Each valve bore end plug can be individually tested in its bore when isolated with a shop rag or small plate to enclose the circuit being pressurized. With a good fit between the end plug OD and valve bore, no leakage should pass between them. Sonnax also offers a Wet Air Test plate, **SWAT-P1**, for easier testing.

# Instructions

- 1. Remove the original end plugs from the valve body and discard.
- 2. Pre-lube o-rings with assembly lube or Transjel<sup>TM</sup>, then install o-rings into the outer groove of Sonnax plugs.
- 3. For easier installation, roll end plug on a clean flat surface to compress o-ring into groove.
- 4. Push end plug into valve bore until aligned with retaining clip opening.

\*Note: small plug, 56947-SML must go into bore o-ring end first.

5. Install OE retaining clip and seat it.

