

GM POWERGLIDE

HIGH GEAR CLUTCH DRUM KIT

HIGH PERFORMANCE TRANSMISSION PARTS

Part No. 28755-01K 1 High Gear Clutch Drum Kit

Note: Patent Pending



INSTALLATION INSTRUCTIONS:

The 28755-01K drum assembly comes with the precision bushing 28005 already installed. When using worn or refinished pumps or any pump with a drum piloting diameter that does not meet OEM specifications, the finish-in-place bushing 28005X should be used.

To use the the **28005X** bushing:

- 1. Disassemble the drum assembly, removing the steels, frictions, snap rings, piston, springs and spring retainers. After that, drive the precision bushing from the ID of the drum. **Note:** Take care not to damage or score the drum **28755-01**.
- 2. Using an appropriate bushing driver, install the FIP bushing 28005X.
- 3. Measure the mating diameter of the pump.
- 4. Chuck the drum 28755-01 into a lathe, taking care not damage the drum.
- 5. Bore the ID of the finish-in-place bushing to be .002-.003" larger than what was measured under step 3.
- 6. Thoroughly clean the drum 28755-01K and bushing 28005X.
- 7. Reassemble the complete drum. Make sure to use assembly lube on the two lip seals.

©2004 Sonnax® 28755-01K(in)06-17-04