PART NUMBERS 12962N-01K, -02K

Upgraded Piston Retainer

Standard Diameter 42RH/RE

12962N-01K

6-Bolt Piston Retainer


Oversized 42RH/RE

12962N-02K

6-Bolt Piston Retainer


Allows damaged reverse drum to be machined and salvaged

Note: U.S. Patent No. 6,810,771



Installation Instructions

- 1. If the oversized support (larger diameter where drum rides) is being used, turn the reverse drum I.D. to 1.966"/1.967". It is important to achieve a surface finish of 16 Ra (comparable to a ground finish) or smoother to increase the life of the unit.
- 2. It is recommended that you drill a small .040"-.045" hole in the case to help lubricate the low roller clutch. See Figure 1 for the exact location of the hole. This process is not a requirement to use the Sonnax retainer.
- 3. Install the o-ring into the o-ring groove and lubricate with TransJel®.
- 4. If the retainer is being installed on an 46RE unit, press the two aluminum plugs into the governor tube holes (See Figure 2).
- 5. Assemble the transmission following normal procedures.
- 6. The SonnaflowTM should be used to verify cooler flow after the rebuild (See Figure 3).






PART NUMBERS 12962N-01K, -02K


Figure 2



Installing the two plugs included with the retainer allows for use on an RE (computer-controlled units).

Figure 3
Problems Diagnosed by SonnaFlow™





Some cases vary in the size of their bore where the area below the o-ring rides. Do not try to drive or press the support into the case. If the support will not fit by hand (you may need a little pressure), you will have to hone about .005" off the I.D. of the case bore.

Do not to stake the plugs: staking the plugs can cause leaks between the support and case.