
MERCEDES 722.3, 722.5, 722.6

PART NUMBER 68004-02

Oversized Pump Bushing

68004-02

1 Finish-in-Place Pump Bushing



INSTRUCTIONS

This is an oversized finish-in-place bushing designed for damaged pump housings. The pump housing bushing bore ID will require machining. This ID must be machined to $\emptyset 2.0000"$ +/- .0005" ($\emptyset 50.800mm$ +/- 0.013mm).

After installation, the bushing ID must be machined to set the desired clearance with the converter hub. Recommended clearance is .002-.005". Measure the OD of the mating converter hub, add .002-.005", and machine the ID of the installed bushing to the calculated dimension.

INSTALLATION

- 1. Remove and discard the OEM bushing.
- 2. Machine the pump housing bore ID to 2.0000" +/- .0005" (Ø50.800mm +/- 0.013mm).
- 3. The post-machining surface finish of the pump housing bore must be Ra60 Ra125.
- 4. Install the new Sonnax bushing.
- 5. Machine in place the newly installed bushing. The surface finish should be Ra30 or better.

