
MERCEDES 722.6 EARLY RWD

PART NUMBER 68410-05

K2 Clutch Drum Bearing Race

68410-05 1 Bearing Race





INSTALLATION / ASSEMBLY STEPS:

- 1. Hard turn output shaft to specifications shown in Figure 1 on the following page. Shaft tolerances must be maintained to ensure proper operational clearances.
- 2. Remove any burrs.
- 3. Check fit of bearing race to shaft.
 - a. For slip fits, Loctite® race to shaft using Loctite® sleeve retainer #609 (or equivalent). Bearing race must butt up against shoulder..
 - b. For interference/press fits, the easiest way to fit the bearing race onto the shaft is by pre-heating the bearing race to 175-200° Fahrenheit in an oven. Lightly lubricate the seating surface of the shaft, using an arbor press and an arbor as shown in Figure 2 on the following page. Bearing race must butt up against shoulder.
- 4. After installation, check for correct operation of the bearing arrangement.

