# 400, 4L80-E

# **REAR UNIT ENDPLAY SHIMS**

#### HIGH PERFORMANCE TRANSMISSION PARTS

#### Part No.

## 34006-05

10 Shims, .005" Thick

### **INSTALLATION INSTRUCTIONS**

- 1. Assemble unit up to and including center support.
- 2. With dial indicator, check endplay of output shaft.
- 3. Add .005" shims under 4-tab thrust washer to obtain desired .005" .025" rear unit endplay.
- 4. Further adjustments can be done in combination with the OEM spacers listed below.

REAR UNIT ENDPLAY		
<b>OEM Shims</b>	I.D. Notch	No.
.074"078"	None	1
.082"086"	On the side of 1 tab	2
.090"094"	On the side of 2 tabs	3
.098"102"	On the end of 1 tab	4
.106"110"	On the end of 2 tabs	5
.114"118"	On the end of 3 tabs	6

©2006 Sonnax Industries, Inc. 34006-05 (in) 05-31-06