PART NUMBERS 77731-RK. -02K

Rear Planetary Rebuild Kit

77731-RK

For 4-Pinion Planets

4 Pinion Gears

4 Pinion Pins

80 Rollers

8 Washers (round)

8 Bat Wing Washers

77731-02K

Pinion Pin Kit

4 Pins

Note: Pinion endplay factory specification of between .008" to .024".

Also available separately

77731-01

1 Pinion Gear

77731-03

80 Needle Rollers

77731-04

1 Round Washer

77731-05


1 Batwing Washer

77731-08

1 Oil Deflector

77731-09

1 Thrust Bearing



Installation Instructions

- 1. Inspect the carrier for cracks or spline wear.
- 2. When replacing the bat wing and steel thrust washers, the steel washer should be sandwiched between the helical gear and the bat wing washer. The bronze bat wing washer should be positioned such that the diagonal recessed oil groove is facing the steel washer, and the solid back is facing the reaction carrier.
- 3. Each helical gear should have 20 needle roller bearings surrounding the bore. A convenient method of holding these bearings in place during assembly is by using a shortened pin and Trans-JelTM.
- 4. When inserting the pinion pin, make sure that the opening to the axial blind hole is facing the top of the carrier, as indicated below. This will allow the oil deflector to direct lube down the pin hole and toward the needle rollers.
- 5. Stake the pinion pins in place such that the ends do not protrude past the recessed pockets in the reaction carrier. The pins should be staked on both ends.
- 6. It is recommended, especially in heavy-duty applications, to use the stamped oil deflector 77731-08 for added lubrication. This deflector is pressed onto the top of the reaction carrier after all necessary bearings, pins, washers, and gears have been replaced.

Note: When rebuilding individual gear assemblies, the best fix is obtained using only Sonnax gears, pinion pins and rollers.

