PART NUMBERS 36941-03-BST


## Line Pressure Coasting Regulator Valve & Bore Sizing Tool

## 36941-03

1 Line Pressure Coasting Regulator Valve



## **36941-BST**1 Bore Sizing Tool



## **Instructions:**

- 1. Remove the upper valve body shift valve plate. Take care not to lose the intermediate servo modulator valve spring when removing the plate.
- 2. Remove the OEM line pressure coasting regulator valve.
- 3. Use the bore-sizing tool Sonnax **36941-BST** to straighten out the OEM valve bore. Place the small diameter of the bore-sizing tool into the valve bore and press the tool until it goes full depth and bottoms out on the end of the valve bore.
- 4. Remove the sizing tool and check to see if the valve moves freely within the bore.
- 5. If the valve does not move freely, reinstall the bore-sizing tool and tap the sizing tool up and down using a hammer and screwdriver as shown in Figure 1. This will smooth out any ridges in the bore. Repeat this process until the valve strokes freely.
- 6. Clean any debris generated from the bore straightening operation from the valve bore.
- 7. Install the Sonnax replacement line pressure coasting regulator valve 36941-03 into the resized valve bore.
- 8. Reinstall the intermediate servo modulator valve spring into its proper bore.
- 9. Reinstall the valve body shift plate.

