


HIGH PERFORMANCE TRANSMISSION PARTS

Part No. 77917-RV

Spring Spacer



INSTRUCTIONS

To install the Sonnax pump slide spring spacer, place the two OEM springs over the spacer stem, and reinsert into the pump cavity with the large spacer diameter seated against the pump wall. Refer to the picture above for proper arrangement.

©2004 Sonnax° 77917-RV 05-11-04