THM 200C, 200-4R

PART NUMBERS 65754-01K, -02K, -03K

Throttle Valve Sleeve Kits


65754-01K

65754-02K

65754-03K

Each includes the following

- 1 TV Plunger
- 1 TV Sleeve



Installation Instructions

- 1. Remove the original throttle valve plunger and sleeve from the valve body and discard.
- 2. Locate the OEM TV valve. The Sonnax replacement kit should have the same number of plunger identification grooves as the number of ribs (1, 2 or zero) as the TV valve.
- 3. Lube replacement plunger and sleeve.
- 4. Insert the plunger into the sleeve in the orientation shown on the opposite page.
- 5. Push this assembly into the valve body bore, just far enough to reinsert the roll pin.
- 6. The grooved diameter of the throttle valve plunger should be sticking out of the valve body bore.

