

**PART NUMBER 96803-01K** 


## 1-2 Accumulator Sleeve & Piston Kit

## 96803-01K

1 Piston

1 Sleeve

1 D-Ring



## **Instructions:**

- 1. Remove any burrs and/or raised areas from the accumulator bore.
- 2. Thoroughly clean out any debris and grease from bore.
- 3. Apply Loctite 609® or equivalent sleeve retaining compound to both the outside of the sleeve and the channel plate bore.
- 4. Place the sleeve over the bore with its chamfered end facing up.
- 5. Push sleeve into bore until it contacts ridge near bottom of bore. If necessary, use original piston as a driver to seat the piston in the bore.
- 6. Allow sleeve retaining compound to cure before any oil pressure is applied to accumulator.
- 7. Install Sonnax piston and D-ring seal with OE pin and springs as normal. Apply Transgel to the D-ring during assembly.

