

PART NUMBER 86539-Z5

Selective Idler Gear Shim

86539-**Z**5

10 Shims (.005" thick)


Also Available:

86940-01

Throttle Plunger Sleeve

86940-03

Throttle Control Valve Sleeve



Installation Instructions

If, after replacing worn components of the idler gear assembly, the correct preload is not obtained, perform the following steps.

- 1. Remove one tapered roller bearing (closest to shaft threads) from the shaft and insert the appropriate number of shims between the bearing to acquire a preload of .001" - .003", or turning torque of 5 - 10 inch lbs. (Measured endplay minus desired preload equals shim stack height.)
- 2. Return bearing to idler shaft.
- 3. Return idler gear assembly to case and mount 32mm, 12 point idler shaft locknut from opposite case side.
- 4. Insert 12mm allen wrench into idler gear and wedge between band anchor strut and case. Using 32mm, 12 point socket, torque locknut to 110 - 130 ft. lbs.

