JATCO/NISSAN

PART NUMBERS 113741-04K, F-113741-TL4

Oversized TCC Limit & Lube Valve Kit

113741-04K



1 O/S TCC Limit & Lube Valve

1 End Plug


1 Spring

NOTE: Fits JF010E & JF011E

F-113741-TL4

- 1 Reamer
- 1 Reamer Jig
- 1 Guide Pin

NOTE: Sonnax tool kits designed to service a specific bore require the Sonnax VB-FIX, a self-aligning valve body reaming fixture. More information and instructions are available at www.sonnax.com.



Disassembly

- 1. Remove and discard the OEM valve, spring and end plug.
- 2. Keep the OEM retainer for reuse.

Important Notes

- 1. Clean the bore thoroughly in a solvent tank.
- 2. Generously lubricate the bore and reamer with cutting fluid (i.e. Mobilmet S-122, Lubegard Bio-Tap, Tap Magic™, etc.). For best results, provide a continuous flow of water-soluble cutting fluid (i.e. Mobilment S-122) during the reaming process.
- 3. The reamers should be turned using a low RPM, high torque air drill regulated to a maximum of 200 RPM.
- 4. Examine the bore after cleaning for surface finish, debris, and burrs. Flashing and burrs on the exit side of land and bores must be carefully removed. A small piece of Scotchbrite™ material attached to a wire and powered with a drill motor is ideal for the task.

Cautions and Suggestions


- 1. Turning the reamer backward will dull it prematurely.
- 2. Pushing on the reamer will result in poor surface finish and inadequate and sporadic material removal.
- 3. Never use a crescent wrench, ratchet or pliers to turn the reamer.
- 4. A dull reamer will cut a smaller hole. Reamers can be sharpened, but should only be done by a professional tool sharpener. Actual life of a reamer before resharpening or replacing averages 50-70 bores.



JATCO/NISSAN CVT

PART NUMBERS 113741-04K, F-113741-TL4

Reaming Instructions




Installation

- 1. Remove all debris from the valve bores and body.
- 2. Install the Sonnax regulator valve.
- 3. Install the Sonnax spring.

- 4. Install the Sonnax end plug.
- 5. Reinstall the OEM retaining clip.

Final Verification Steps

Perform a vacuum/wet air test. Either port should yield 18" of vacuum or higher.



©2010 Sonnax Industries, Inc.

113741-04K Rev:-, F-113741-04K-TL Rev:-, 113741-04K-IN 07-19-10

