PART NUMBER F-15741-TL29PL

Adapter Plate for VB-FIX

F-15741-TL29PL

1 Adapter Plate

1 Screw M5-0.8 x 12mm 1 Screw M5-0.8 x 15mm 1 Screw M5-0.8 x 25mm

Required to install 15741-18K and 15741-29K in: Volvo (AM6); Opel (AF40); Peugeot (TF80); Saab (AF40/6); Land Rover (TF80); BMW (6F21WA) & VW/Audi (09G, 09K, 09M).

The above Adapter Plate is used with these products below:

Solenoid Modulator Valve Kit

15741-18K

Tool Kit Required

Tool Kit for above kit

F-15741-TL18 VB-FIX Required

Lockup Clutch Control Valve Kit

15741-29K


Tool Kit Required

Tool Kit for above kit


F-15741-TL29 VB-FIX Required

Reaming Fixture VB-FIX

12mm Screw










TF-60SN Upper Valve Body #2 & Adapter Plate Configuation



Installation & Assembly Steps

- 1. Mount either valve body section to the plate using two screws.
 - TF-80SC uses one 12mm & one 15mm long screw.
 - TF-60SN uses one 12mm & one 25mm long screw.
- 2. When properly mounted the TC lockup clutch control bore center-line will be visible through the slot in the plate.
- 3. Place the adapter plate and valve body section onto the reaming fixture VB-FIX. Align and secure the valve body and adapter plate to the fixture according to the VB-FIX instructions, using the guide pin and reamer jig from either the F-15741-TL18 or F-15741-TL29 tool kits.
- 4. Clamp the adapter plate to the **VB-FIX**. Do not clamp on the valve body.
- 5. Follow the reaming, cleaning and assembly instructions included with either repair kit 15741-18K or 15741-29K.

