# AXOD & E, AX4S


PART NUMBERS 96511K, 96512K, 96513K, 965123K

## **Accumulator Bore Sleeve Kits**

96511K	(N-D)
96512K	(3-4)
96513K	(1-2)
Each kit includes the following	
1 Sleeve	
1 Piston	
1 Viton® O-Ring	

### 965123K

1 Each of the kits above



#### **Wet Air Test**

After all channel casting bolts are torqued, each servo may be tested by pressurizing the pin. No leakage should be exiting from any port. The pin should want to walk out of the channel casting.

#### **Instructions**

Remove any burrs or raised areas from the accumulator bore. Thoroughly clean out any debris or grease. Apply Loctite 609® to sleeve. Place end of sleeve with O.D. chamfer into bore and press in sleeve until it makes contact with the bottom. Install piston, o-ring, pin and springs as you would normally.

