



CARE & FINISHING GUIDE

SourcePoint Heritage Torrefied Wood Doors

Version 1.0 · Keep this guide with your warranty documents.

FINISH THE DOOR BEFORE YOU HANG IT — ALL SIX SIDES

Your ten-year coverage depends on it. Seal the face, the back, both edges, **the top edge, and the bottom edge**, plus every bore hole, mortise pocket, and cut edge. A door with an unsealed top or bottom edge is not covered. **Primer is not a sealer.**

Heritage doors are real wood. Torrefaction makes them far more stable and far more resistant to rot and insects than untreated wood — it does not make them weatherproof or maintenance-free. Everything in this guide exists because wood moves, and a good finish is what keeps it from moving too much.

INSTALLATION

Before and During Installation

- **Unwrap and inspect the door as soon as you receive it — before installation.** Concealed damage is damage you cannot see until the packaging comes off. Report it to your dealer, in writing, within **24 hours of your receipt**. Report any other defect before the door is installed, altered, trimmed, or finished. A door that has been installed or finished is treated as accepted.
- **Store it flat and fully supported**, on a level, dry surface, indoors. Target **25–55% relative humidity and 50–90°F**. Never lean the door against a wall, never leave it outdoors, and never let it sit in standing water. A door that takes on moisture in storage will move after it is hung, and that damage is not covered.
- **Keep the packaging spacers in place** until the door is ready to hang, and keep stacked doors covered.
- **Do not cut down, trim, or add cutouts to the door.** Alterations void coverage.
- Professional installation is strongly recommended. Waterproofing is the customer's responsibility.

FINISHING

Finishing — Required

Every Heritage door must be finished on all six sides before it is installed. You can stain it, clear-finish it, or paint it. What you cannot do is hang it unfinished, or finish it with the wrong product.

Which finish system

IF YOU ARE	USE
Staining or clear-finishing	Spar urethane, spar varnish, or an equivalent marine-grade exterior system formulated for exterior wood, with UV inhibitors
Painting	A quality exterior primer plus exterior-grade paint formulated for exterior wood doors

DO NOT USE INTERIOR POLYURETHANE

Polyurethane is an interior finish. It breaks down and peels under sunlight and weather. A Heritage door finished with polyurethane is not covered.

Primer is not a sealer. A door left in primer only is not protected.

If you are staining

- 1. Use a high-quality stain formulated for exterior use. **Stain all six sides.** Test the color first on a small area of the door edge so you know you like it.
- 2. Let the stain dry and cure for **24 hours.**
- 3. Lightly sand with **220-grit** paper to knock down raised grain, then clean off the dust with a tack cloth. The surface should be smooth again.

Sealing — every door, stained or painted

- 1. Apply your topcoat — spar urethane, spar varnish, or equivalent marine-grade exterior system over stain; exterior-grade paint over exterior primer. Cover all six sides.
- 2. Let it dry and cure **24 hours.**
- 3. Lightly sand and clean as above.
- 4. Apply the final coat. **Do not sand the final coat.**

At installation

Seal every surface you expose by fitting the door — hinge routs, lock bores, mortise pockets, and any trimmed edge — **when you hang it.** Bare wood left open at a bore hole pulls water into the core of the door.

ONGOING CARE

Ongoing Care — Required to Keep Coverage

How often you recoat depends on how exposed the door is. **Heritage does not require an overhang.** What it requires instead is more attention when there isn't one.

YOUR INSTALLATION	INSPECT THE FINISH	RECOAT AT LEAST
Sheltered — overhang meets the standard in your warranty (X = ½Y)	Every 12 months	Every 2 years
Exposed — no overhang, or less than the standard	Every 6 months	Every 12 months

Not sure which you are? Measure from the bottom of the door up to the base of the overhang. The overhang needs to project out from the wall at least **half** that distance. If it does not, you are exposed. The full standard, with a table, is in the **Overhang** section of your warranty.

If your door is exposed, dated records are required. Rot, decay, insect, delamination, and panel-separation claims on an exposed installation need dated proof that the finish was inspected and recoated on schedule. A photograph with the date on it, a contractor's invoice, or the log at the back of this guide all work.

Recoat sooner than the minimum any time the finish looks dull, chalky, thin, or has worn through — particularly on south- and west-facing doors, which take the heaviest sun.

Re-seal immediately any time the finish cracks, peels, or wears through, **especially on the top and bottom edges.** Those are the two surfaces nobody looks at and the two that let water into the door.

Clean the door twice a year with mild detergent and warm water, and wipe off dirt and debris as it accumulates. Debris left sitting on a door holds moisture against the finish and breaks it down.

RECORDS

Keeping Records

Because coverage runs ten years, the maintenance record is what supports a claim a decade from now. Note the date, what you did, and what product you used. Photograph the door once a year if you can. On an exposed installation this is not optional.

THE WOOD

What to Expect from the Wood

- **The color will change.** Torrefied wood starts dark and lightens and grays under ultraviolet light. This is normal weathering, not a defect, and it happens faster on an exposed door.

- **Fine surface checks are normal.** Small checks in the face of a hardwood door are a natural characteristic of the material.
- **The door will move a little with the seasons.** It takes on moisture in humid weather and gives it back in dry weather. Torrefaction greatly reduces this; it does not eliminate it.
- **Panel shrinkage and minor misalignment are normal** and are not defects.

SEASONAL

Seasonal Checks

- Inspect the **top and bottom edges** at every scheduled inspection. These are where finish failures start and where they do the most damage.
- Check that the door still swings freely and closes without binding.
- Confirm the threshold and sill are draining and that sealant at the perimeter is intact.
- Check that no third-party hardware has been fastened through the door.

CONDENSATION

Condensation

Exterior doors can sweat when interior humidity is high or a heat register sits near the door. This is not a manufacturing defect and is not covered, but standing moisture will damage the door, the trim, and the flooring. Wipe it up promptly, lower interior humidity, and run exhaust fans.

VOID CONDITIONS

What Voids Your Warranty

- Hanging the door before it is finished on all six sides
- Finishing with interior polyurethane, or with any product other than a permitted system
- Leaving the door in primer only
- Cutting down, trimming, or adding cutouts to the door
- Fastening third-party items through the door — mail slots, speakeasies, and similar
- Driving fasteners without pilot holes
- **Installing a storm door of any type**, vented or non-vented
- Storing the door improperly before installation
- Failing to inspect and recoat on the schedule above, or failing to keep dated records where they are required

NOT COVERED

What Is Not Covered

These do not void your warranty. The specific damage is simply not covered:

- Damage from heat build-up where a **dark paint or stain** has been used. A dark finish is one with a Light Reflectance Value below 40. The natural color of the torrefied wood itself does not count as a dark finish.
- Normal weathering, color change, and surface checking
- Seasonal movement, panel shrinkage, and minor warp within tolerance
- The performance or appearance of any finish applied by anyone other than SourcePoint
- Condensation and damage resulting from it
- Glass breakage and glass scratches
- Water entering around the door — flashing, sealant, and installation are the installer's responsibility

Maintenance Log

DATE	WHAT YOU DID	PRODUCT USED

Questions about your door? Contact your SourcePoint dealer. They are your first point of contact for product questions, replacement parts, and warranty claims.

SourcePoint Doors and Windows LLC

4363 Northeast Expressway, Atlanta, GA 30340 · sourcepointdoors.com

SourcePoint Doors & Windows · Form SP-WAR-009 · Rev. September 2026 · Version 1.0