USB Host Diagnostics

Please read this document and confirm that:


- Your Android device is running Android 3.1 or later
- Your Android device has a USB Host Controller
- The SecuGen fingerprint reader is recognized by your Android device

 Currently, SecuGen Hamster Plus™ (HSDU03P) and Hamster IV™ (HSDU04P) fingerprint readers are supported. Earlier model numbers not shown here are not supported.

1. Verify that your Android device is running Android 3.1 or later


- a. Run the Settings app and select About Device
- b. Scroll down until you find Android version
- c. It should be 3.1 or later

For example:




2. Verify that your Android device has a USB Host Controller


a. Download and install Chainfire USB Host Diagnostics on your Android device.



b. Unplug all USB devices, and run the USB Host Diagnostics tool.



c. Click **Start Diagnostics.** Click **OK** to confirm that no USB devices are attached.



d. You will receive a prompt asking you to connect a USB device.




e. Plug in the SecuGen USB fingerprint reader using a USB On-The-Go (OTG) cable. If a USB host controller is present, the dialog box above will be dismissed and a Diagnostics Complete message will be displayed as shown below.




f. IMPORTANT: If the Diagnostics Complete message is not displayed when the USB device is plugged in, your Android device does not have a host controller. Select an alternative Android device to work with. Do not contact SecuGen technical support if this test has not passed.

g. Confirm successful completion of the test by verifying that **Device Detected** in the **Kernel** section is set to **Yes**.




3. Verify that the SecuGen fingerprint reader is recognized

a. Download and install the "USB Host Viewer" app




- b. Plug in the SecuGen USB fingerprint reader.
- c. Launch the USB Host Viewer app

d. If the Hamster Plus (HSDU03P) reader is recognized, the following information will be displayed:



e. If the Hamster IV (HSDU04P) reader is recognized, the following information will be displayed:



- f. If any device other than those listed below is displayed, this SDK will not function correctly.
 - i. 1162:1000 Hamster Plus (SDU03P)
 - ii. 1162:2000 Hamster IV (SDU04P)