

Press six $\phi 0.25$ " x 1.5" dowels into the left-most and right-most holes