- Wiring sheet — SV symbols, CRESTRON scenes
  - Steps
  - S-1 — Banquet Room (prefix bq_)
    - Parameters
    - Pins
    - Buttons
  - S-2 — Private Dining (prefix din_)
    - Parameters
    - Pins
    - Buttons
  - Check it works (SIMPL Debugger)

Wiring sheet — SV symbols, CRESTRON scenes

What to type into the two **"Somo SV Basestation (MQTT)"** symbols in Program 01 for the CRESTRON scenes. A scene's pin row is its scene number on that basestation (scene 23 → `Scene_Activate[23]`). Any pin not listed here stays empty.

Steps

1. Compile `SomoSvBasestation.usp`. In Detail View `Scene_Activate` must run to `[32]`; if it stops at `[24]`, recompile, delete the placed symbol, **F5**, drag a fresh one.
2. Place `S-1`. Type the **Banquet** parameters, `Connect 1` and `Disconnect 0`.
3. Clone `S-1` onto a fresh `S-2`: right-click-drag → **Copy All Signals/Parameters**. On `S-2` change `QR_Code` to `SB9SFN712660`.
4. Type the scene pins: Banquet rows **3, 9, 13, 16, 19** on `S-1`; Private Dining rows **23, 24, 25, 26, 27** on `S-2`.
5. Confirm all six parameters are filled on both symbols, then **right-click each symbol → Make Symbol Complete** (it fills every pin not listed here with `//`). **Ctrl+S**, **F12**, load.

S-1 — Banquet Room (prefix `bq_`)

Parameters

Parameter	Type this
`QR_Code`	`SB8AR3046349`
`MQTT_Username`	`crestron`
`MQTT_Password`	`7c61319ee0d58c59328c65e0e2a250240c794c9727c00b3ba3208f69d4bc6d1d` (64 characters — the field's maximum; no spaces)

Parameter	Type this
Broker_Override	mqtt.somo.ai:8883
Default_Ramp_Ms	1000d
Verbose_Logging	0d

Pins

Pin	Type this	CRESTRON scene
Connect	1	required — starts the connection
Disconnect	0	required
Scene_Activate[3]	bq_scene_on[3]	**CRESTRON 01-3**
Scene_Activate[9]	bq_scene_on[9]	**CRESTRON 00-1**
Scene_Activate[13]	bq_scene_on[13]	**CRESTRON 01-2**
Scene_Activate[16]	bq_scene_on[16]	**CRESTRON 01-5**
Scene_Activate[19]	bq_scene_on[19]	**CRESTRON 01-4**
Scene_Deactivate[3]	bq_scene_off[3]	**CRESTRON 01-3**
Scene_Deactivate[9]	bq_scene_off[9]	**CRESTRON 00-1**
Scene_Deactivate[13]	bq_scene_off[13]	**CRESTRON 01-2**
Scene_Deactivate[16]	bq_scene_off[16]	**CRESTRON 01-5**
Scene_Deactivate[19]	bq_scene_off[19]	**CRESTRON 01-4**
Scene_Active_Fb[3]	bq_scene_fb[3]	**CRESTRON 01-3**
Scene_Active_Fb[9]	bq_scene_fb[9]	**CRESTRON 00-1**
Scene_Active_Fb[13]	bq_scene_fb[13]	**CRESTRON 01-2**
Scene_Active_Fb[16]	bq_scene_fb[16]	**CRESTRON 01-5**
Scene_Active_Fb[19]	bq_scene_fb[19]	**CRESTRON 01-4**
Scene_Name_Fb[3]	bq_scene_name[3]	**CRESTRON 01-3**
Scene_Name_Fb[9]	bq_scene_name[9]	**CRESTRON 00-1**
Scene_Name_Fb[13]	bq_scene_name[13]	**CRESTRON 01-2**
Scene_Name_Fb[16]	bq_scene_name[16]	**CRESTRON 01-5**
Scene_Name_Fb[19]	bq_scene_name[19]	**CRESTRON 01-4**

Buttons

Button	Scene	Press →	Off →	LED ←
1	CRESTRON 00-1	`bq_scene_on[9]`	`bq_scene_off[9]`	`bq_scene_fb[9]`
2	CRESTRON 01-2	`bq_scene_on[13]`	`bq_scene_off[13]`	`bq_scene_fb[13]`
3	CRESTRON 01-3	`bq_scene_on[3]`	`bq_scene_off[3]`	`bq_scene_fb[3]`
4	CRESTRON 01-4	`bq_scene_on[19]`	`bq_scene_off[19]`	`bq_scene_fb[19]`
5	CRESTRON 01-5	`bq_scene_on[16]`	`bq_scene_off[16]`	`bq_scene_fb[16]`

⚠ Banquet's button-1 scene is named `CRESTRON 00-1` in the configurator (not `01-1`). Its row is 9 either way.

S-2 — Private Dining (prefix `din_`)

Parameters

Parameter	Type this
`QR_Code`	`SB9SFN712660`
`MQTT_Username`	`crestron`
`MQTT_Password`	`7c61319ee0d58c59328c65e0e2a250240c794c9727c00b3ba3208f69d4bc6d1d` (64 characters — the field's maximum; no spaces)
`Broker_Override`	`mqtt.somo.ai:8883`
`Default_Ramp_Ms`	`1000d`
`Verbose_Logging`	`0d`

Pins

Pin	Type this	CRESTRON scene
`Connect`	`1`	required — starts the connection
`Disconnect`	`0`	required
`Scene_Activate[23]`	`din_scene_on[23]`	**CRESTRON 01-1**
`Scene_Activate[24]`	`din_scene_on[24]`	**CRESTRON 01-5**
`Scene_Activate[25]`	`din_scene_on[25]`	**CRESTRON 01-2**
`Scene_Activate[26]`	`din_scene_on[26]`	**CRESTRON 01-3**
`Scene_Activate[27]`	`din_scene_on[27]`	**CRESTRON 01-4**
`Scene_Deactivate[23]`	`din_scene_off[23]`	**CRESTRON 01-1**

Pin	Type this	CRESTRON scene
Scene_Deactivate[24]	din_scene_off[24]	**CRESTRON 01-5**
Scene_Deactivate[25]	din_scene_off[25]	**CRESTRON 01-2**
Scene_Deactivate[26]	din_scene_off[26]	**CRESTRON 01-3**
Scene_Deactivate[27]	din_scene_off[27]	**CRESTRON 01-4**
Scene_Active_Fb[23]	din_scene_fb[23]	**CRESTRON 01-1**
Scene_Active_Fb[24]	din_scene_fb[24]	**CRESTRON 01-5**
Scene_Active_Fb[25]	din_scene_fb[25]	**CRESTRON 01-2**
Scene_Active_Fb[26]	din_scene_fb[26]	**CRESTRON 01-3**
Scene_Active_Fb[27]	din_scene_fb[27]	**CRESTRON 01-4**
Scene_Name_Fb[23]	din_scene_name[23]	**CRESTRON 01-1**
Scene_Name_Fb[24]	din_scene_name[24]	**CRESTRON 01-5**
Scene_Name_Fb[25]	din_scene_name[25]	**CRESTRON 01-2**
Scene_Name_Fb[26]	din_scene_name[26]	**CRESTRON 01-3**
Scene_Name_Fb[27]	din_scene_name[27]	**CRESTRON 01-4**

Buttons

Button	Scene	Press →	Off →	LED ←
1	CRESTRON 01-1	din_scene_on[23]	din_scene_off[23]	din_scene_fb[23]
2	CRESTRON 01-2	din_scene_on[25]	din_scene_off[25]	din_scene_fb[25]
3	CRESTRON 01-3	din_scene_on[26]	din_scene_off[26]	din_scene_fb[26]
4	CRESTRON 01-4	din_scene_on[27]	din_scene_off[27]	din_scene_fb[27]
5	CRESTRON 01-5	din_scene_on[24]	din_scene_off[24]	din_scene_fb[24]

Check it works (SIMPL Debugger)

Banquet	Private Dining	Expect
bq_scene_name[9]	din_scene_name[23]	CRESTRON 00-1 / CRESTRON 01-1
bq_scene_name[13]	din_scene_name[25]	CRESTRON 01-2
bq_scene_name[3]	din_scene_name[26]	CRESTRON 01-3
bq_scene_name[19]	din_scene_name[27]	CRESTRON 01-4

Banquet	Private Dining	Expect
`bq_scene_name[16]`	`din_scene_name[24]`	`CRESTRON 01-5`

Then pulse each `_scene_on[…]`: the scene's fixtures respond and the matching `_scene_fb[…]` goes high; `_scene_off[…]` turns them off. An empty name means the symbol isn't connected yet — check `QR_Code`, the password, and the network.