Direction "from"

Key	Value	Meaning
energyStorage	0 ... 100 [%], step 6.667	Energy Storage
energyStorageAvailability	available	Energy storage data is available
	unavailable	Energy storage data is unavailable
illuminance	0 ... 65535 [lx], step 1	Illuminance (linear)
temperature	-20 ... 60 [°C], step 0.314	Ambient Temperature
temperatureAvailability	available	Temperature data is available
	unavailable	Temperature data is unavailable