Direction "from"

Key	Value	Meaning
setpoint	0 ... 255, step 1	Set point (manufacturer specific)
temperature	0 ... 40 [°C], step 0.157	Temperature (linear)