Direction "from"

Key	Value	Meaning
channel	0 ... 15, step 1	Tariff info
volume	0 ... 16777215000 [l], step 1	Cumulative water volume

Direction "from"

Key	Value	Meaning
channel	0 ... 15, step 1	Tariff info
flowrate	0 ... 16777215 [l/s], step 1	Current water flow rate