Direction "from"

Key	Value	Meaning
azimuth	0 ... 359 [°], step 1	Azimuth (0° -> True north clockwise)
elevation	-90 ... 90 [°], step 1	Elevation (0° -> horizon)