Direction "from"

Key	Value	Meaning
batteryLow	false	Battery ok
	true	Battery low
windDirection	22.5 ... 360 [°], step 22.5	Current wind direction: NNE, NE, ENE, E, …, NNW, N
windSpeedAverage	0 ... 89.36 [m/s], step 0.35	Linear average wind speed up to 199.9 mph
windSpeedMax	0 ... 89.36 [m/s], step 0.35	Maximum wind speed up to 199.9 mph