Direction "from"

Key	Value	Meaning
temperature	0 ... 40 [°C], step 0.157	Temperature (linear)
valve	0 ... 100 [%], step 1	Actual valve position

Direction "to"

Key	Value	Meaning
setpointInverse	false (default)	Set point of valve is normal
	true	Set point of valve is inverse
temperature	0 ... 40 [°C], step 0.157	Temperature from Room Control Unit
valve	0 ... 100 [%], step 1	Actuator setpoint: In combination with BAS/Gateway controllers.

Direction "to"

Key	Value	Meaning
temperature	0 ... 40 [°C], step 0.157	Temperature from Room Control Unit
temperatureSetpoint	0 ... 40 [°C], step 0.157	Temperature setpoint: The actuator can be used as self-sufficient room controller (pi controller) without integration in automation systems.