Direction "from"

Key	Value	Meaning
batteryLow	false	Battery is OK
	true	Battery is low
contact	closed	Contact is closed
	open	Contact is open