Direction "to": Actuator Set Output

Key	Value	Meaning
switch	off	Output value OFF
	on	Output value ON

Direction "from": Actuator Status Response

Key	Value	Meaning
switch	off	Output value OFF
	on	Output value ON

Direction "to": Actuator Query

Key	Value	Meaning
query	status	Query status