Direction "to": Actuator Set Output

Key	Value	Meaning
switch	off	Output value OFF
	on	Output value ON

Direction "to": Configure Actuator

Key	Value	Meaning
defaultState	off	Default state: OFF
	on	Default state: ON
	previousState (default)	Default state: remember previous state
localControl	off	Disable local control
	on (default)	Enable local control
powerFailureDetection	off	Disable Power Failure Detection
	on (default)	Enable Power Failure Detection
taughtInDevices	off	Disable taught-in devices (with different EEP)
	on (default)	Enable taught-in devices (with different EEP)
userInterfaceIndication	day (default)	User interface indication: day operation
	night	User interface indication: night operation

Direction "from": Actuator Status Response

Key	Value	Meaning
localControl	off	Local control disabled / not supported
	on	Local control enabled
powerFailureDetected	false	Power Failure not detected/not supported/disabled
	true	Power Failure Detected
powerFailureDetection	off	Power Failure Detection disabled/not supported
	on	Power Failure Detection enabled
switch	off	Output value OFF
	on	Output value ON

Direction "to": Actuator Query

Key	Value	Meaning
query	status	Query status