Direction "to": Go to Position and Angle

Key	Value	Meaning
angle	0 ... 100 [%], step 1	Rotation angle
	noChange (default)	Do not change
lockingMode	alarm	Set alarm mode
	block	Set blockage mode
	noChange (default)	Do not change
	unblock	Deblockage
position	0 ... 100 [%], step 1	Vertical position
	noChange (default)	Do not change
repositioning	direct (default)	Go directly to POS/ANG
	firstDown	Go down (100%), then to POS/ANG
	firstUp	Go up (0%), then to POS/ANG

Direction "to": Stop

Key	Value	Meaning
stop	true	Stop command

Direction "to": Query Position and Angle

Key	Value	Meaning
query	status	Query command

Direction "from": Reply Position and Angle

Key	Value	Meaning
angle	0 ... 100 [%], step 1	Current rotation angle
	unknown	Angle currently unknown
lockingMode	alarm	Alarm mode
	block	Blockage mode
	unblock	Normal (no lock)
position	0 ... 100 [%], step 1	Current vertical position
	unknown	Position currently unknown

Direction "to": Set parameters

Key	Value	Meaning
alarmAction	goDown	Besides locking all other commands entering the alarm mode results in go down (100%)
	goUp	Besides locking all other commands entering the alarm mode results in go up (0%)
	noAction	Besides locking all other commands entering the alarm mode results in no action
	noChange (default)	Do not change
	stop	Besides locking all other commands entering the alarm mode results in immediate stop
rotationTime	10 ... 2540 [ms], step 10	Measured duration of rotation
	noChange (default)	Do not change
	noRotation	No rotation
verticalMovementTime	5000 ... 300000 [ms], step 10	Measured duration of a vertical run
	noChange (default)	Do not change