Ip representation:D2-07-01

IP KEY	Valid range	Step size	Unit	IP Meaning
Lock number	0...65535	1		Lock number
Lock state	0			Lock open
	1			Lock closed
	2			Lock usable for a time
	3			Lock blocked
DND state	0			DND not active
	1			DND active
Event type	0			Lock used
	1			Lock programmed
	2			Lock resetted
	3			Lock protocolls read
	4			Battery changed
Key type	0			User Key
	1			Master Key
	2			Housekeepin Key
Type of actuation	0			RFID
	1			PIN-Code
	2			Bluetooth
Actuation identifier	0...72057594037927935	1		Actuation identifier, this can be the UID of RFID, MAC Adresss or a PIN-Code
Reason for rejection	0			No rejection
	1			Key not valid yet
	2			Key not valid any more
	3			Key with wrong generation
	4			Key not allowed at this lock
	5			DND active
	6			Timezone not active
	7			PIN-Code not allowed
	8			Usercount exceeded

IP KEY	Valid range	Step size	Unit	IP Meaning
	9			Lock blocked
Alarm state	0			No alarm
	1			Alarm active