Direction "from": EPAC

Key	Value	Meaning
activity	0 ... 100, step 1	Activity[%]=(PIRCounterCurrentTel - PIRCounterLastTel)* (time[s]/(ArrivalCurrentTel[s] - ArrivalPreviousTel[s]))
	unavailable (default)	Activity is currently not availble
energyStorage	critical	Critical
	high (default)	High
	low	Low
	medium	Medium
pirCounter	0 ... 65535 [Activations], step 1	Amount of times that PIR activity has been counted.
presence	noPresenceDetected (default)	Not present
	presenceDetected	Present
	presenceDetectionError	Presence Detection Error
	presenceNotDetectable	Not detectable
time	1 ... 16 [s], step 1	Discrete interval in which the activity is considered.