D2-34-00 … D2-34-02

Direction "to": Actuator Status Query

key	value	meaning
query	status	
channel	1…30	channel address of sensor
	allChannels	All channels suported by the device

Direction "from": Actuator Status Response

key	value	meaning
temperature	0…40 [°C] step 0.1	current room temperature
	unkonwn	temperature is unknown
temperatureSetpoint	0…40 [°C] step 0.1	currently active set point
mode	off	deactivated
	unknown	Temperature unknown
	No heating required', 'Heating required']	
channel	1…30	channel address of sensor
	allChannels	All channels suported by the device (Asked AWAG, if this value can ever be sent in a response)

Direction "to": Actuator Set Point Configuration Room panel

channel	1…30	channel address of sensor
	allChannels	All channels suported by the device

Direction "to": Actuator Set Point Configuration Overwrite

duration	1…63 [h] step 1	duration of the override until fallback
	endless	
setpoint	0…40 [°C] step 0.1	set point to overwrite
channel	1…30	channel address of sensor
	allChannels	All channels suported by the device

Direction "to": Actuator Set Point Configuration Add shift value

duration	1…63 [h] step 1	duration of the override until fallback
	endless	
setPointShiftAdd	0…10 [K] step 0.1	
channel	1…30	channel address of sensor
	allChannels	All channels suported by the device

Direction "to": Actuator Set Point Configuration Subtract shift value

duration	1…63 [h] step 1	duration of the override until fallback
	endless	
setPointShiftSub	0…10 [K] step 0.1	
channel	1…30	channel address of sensor
	allChannels	All channels suported by the device

Direction "to": Actuator Set Point Query

key	value	meaning
query	setPoint	
channel	1…30	channel address of sensor
	allChannels	All channels suported by the device

Direction "from": Actuator Set Point Response Room panel value

key	value	meaning
channel	1…30	channel address of sensor
	allChannels	All channels suported by the device

Direction "from": Actuator Set Point Response Overwrite

remainingDuration	1…63 [h] step 1	remaining duration of the override until fallback
	endless	
	expired	
temperatureSetpoint	0…40 [°C] step 1	currently stored set point
channel	1…30	channel address of sensor
	allChannels	All channels suported by the device

Direction "from": Actuator Set Point Response Add shift value

remainingDuration	1…63 [h] step 1 endless expired	remaining duration of the override until fallback
setPointShiftAdd	0…10 [K] step 0.1	
channel	1…30	channel address of sensor

Direction "from": Actuator Set Point Response Subtract shift value

remainingDuration	1…63 [h] step 1 endless expired	remaining duration of the override until fallback
setPointShiftSub	0…10 [K] step 0.1	
channel	1…30	channel address of sensor