Direction "from"

Key	Value	Meaning
valve	close	Valve is closed
	open	Valve is opened
	undefined	State of valve is undefined or valve is actually moving

Direction "to"

Key	Value	Meaning
valve	close	Request to close valve
	open	Request to open valve
	query	Request to query state of valve