Direction "from"

Key	Value	Meaning
multipleButtons	pressed	3 or 4 buttons pressed
	released	3 or 4 buttons released

Direction "from"

Key	Value	Meaning
buttonA0	pressed	Button pressed
	released	Button released
buttonAI	pressed	Button pressed
	released	Button released
buttonB0	pressed	Button pressed
	released	Button released
buttonBI	pressed	Button pressed
	released	Button released
buttonC0	pressed	Button pressed
	released	Button released
buttonCI	pressed	Button pressed
	released	Button released
buttonD0	pressed	Button pressed
	released	Button released
buttonDI	pressed	Button pressed
	released	Button released