



Drone Tracker Marker Sheet

Print at 100% / Actual Size. Do NOT use 'Fit to Page' or 'Scale'.


Scale verification bar: 100 mm



Measure with a ruler. If it isn't exactly 100 mm, your printer is scaling. Re-print at 100% / Actual Size.



Primary marker - 50.0 mm diameter



Backup marker - 30.0 mm diameter (for smaller mounts)

Mount + use:

1. Verify the scale bar above measures exactly 100 mm with a ruler. If not, re-print at 100%.
2. Cut along the dashed line around the marker you want.
3. Stick it FLAT on the drone belly. Curling makes it look like an ellipse and throws off the math.
4. After mounting, measure the printed circle with calipers and use THAT number in the firmware, not the nominal 50.0 mm. A 2% print error = 2% Z error.

Firmware constant:

```
const float MARKER_DIAMETER_MM = 50.0;    // <-- set to your measured value
```